




MPI MAIN RELAY



MPI MAIN RELAY ("EFI") INSPECTION ^{0019W-01}

1. REMOVE MPI MAIN RELAY




2. INSPECT MPI MAIN RELAY

A. Inspect relay continuity

- (a) Using an ohmmeter, check that there is continuity between terminals 1 and 3.
- (b) Check that there is no continuity between terminals 2 and 4.

If continuity is not as specified, replace the relay.



B. Inspect relay operation

- (a) Apply battery voltage across terminals 1 and 3.
- (b) Using an ohmmeter, check that there is continuity between the 2 and 4.

If operation is not as specified, replace the relay.

3. REINSTALL MPI MAIN RELAY