




# VSV (For Fuel Pressure)




# COMPONENTS FOR REMOVAL AND INSTALLATION

EG0E2-07



P04304



P05352


## VSV INSPECTION

R0148-01

(See Components for Removal and Installation)

### 1. DISCONNECT CABLE FROM NEGATIVE TERMINAL OF BATTERY

**CAUTION:** Turn the ignition switch to 'LOCK'. Disconnect the negative terminal from the battery. Wait at least 20 seconds before proceeding with work.




P04197


### 2. REMOVE VSV

(a) Disconnect the following connector and hoses:

- (1) VSV connector
- (2) Vacuum hose (from fuel pressure regulator) from port E of VSV
- (3) Vacuum hose (from gas filter) from port G of VSV



- (b) Remove the two bolts and VSV. Disconnect the two ground straps.



### 3. INSPECT VSV


#### A. Inspect VSV for open circuit

Using an ohmmeter, check that there is continuity between the terminals.

#### Resistance (Cold):

**37–44 Ω**


If there is no continuity, replace the VSV.



#### B. Inspect VSV for ground


Using an ohmmeter, check that there is no continuity between each terminal and the body.

If there is continuity, replace the VSV.




#### C. Inspect VSV operation

- (a) Check that the air flows from port E to port G.




- (b) Apply battery voltage across the terminals.  
 (c) Check that the air flows from port E to the filter.  
 If operation is not as specified, replace the VSV.



#### 4. REINSTALL VSV

- (a) Install the VSV with the bolt. Connect the two ground straps.



- (b) Connect the following connector and hoses:
- (1) VSV connector
  - (2) Vacuum hose (from fuel pressure regulator) from port E of VSV
  - (3) Vacuum hose (from gas filter) from port G of VSV

#### 5. RECONNECT CABLE TO NEGATIVE TERMINAL OF BATTERY