




# CLUTCH UNIT COMPONENTS

CL01Y-01



## CLUTCH UNIT REMOVAL

CL01Z-01

### 1. REMOVE TRANSAXLE


(See page S54 [MX-8](#) and E153 [MX-9](#))

### 2. REMOVE CLUTCH COVER AND DISC

- Put matchmarks on the clutch cover and flywheel.
- Loosen the set bolts one turn at a time until spring tension is released.
- Remove the set bolts and pull off the clutch cover and disc.

### 3. REMOVE BEARING, HUB AND FORK FROM TRANSAXLE

- Remove the retaining clip, pull off the bearing.
- Remove the fork and boot.



CL0239

## CLUTCH PARTS INSPECTION


### 1. INSPECT CLUTCH DISC FOR WEAR OR DAMAGE

Using calipers, measure the rivet head depth.

**Minimum rivet depth:**

**0.3 mm (0.012 in.)**

If a problem is found, repair or replace the clutch disc.



CL0373


### 2. INSPECT CLUTCH DISC RUNOUT

Using a dial indicator, check the disc runout.

**Maximum runout:**

**0.8 mm (0.031 in.)**

If runout is excessive, replace the disc.



CL0372


### 3. INSPECT FLYWHEEL RUNOUT

Using a dial indicator, check the flywheel runout.

**Maximum runout:**

**0.1 mm (0.004 in.)**

If runout excessive, repair or replace flywheel.



CL0404

### 4. INSPECT DIAPHRAGM SPRING FOR WEAR


Using calipers, measure the diaphragm spring for depth and width of wear.

**Maximum:**

**Depth 0.6 mm (0.024 in.)**

**Width 5.0 mm (0.197 in.)**

If necessary, replace the clutch cover.




001343

### 5. INSPECT RELEASE BEARING

Turn the bearing by hand while applying force in the rotation direction.

If the bearing sticks or has much resistance, replace the release bearing.


**HINT:** The bearing is permanently lubricated and requires no cleaning or lubrication.



## CLUTCH UNIT INSTALLATION

### 1. INSTALL DISC ON FLYWHEEL

Using SST, install the disc on the flywheel.  
 SST 09301 -00220 (3S-GTE)  
 09301 -00210 (5S-FE)




### 2. INSTALL CLUTCH COVER

(a) Align the matchmarks on the clutch cover and flywheel.

(b) Torque the bolts on the clutch cover in order shown.

**Torque: 19 N-m (195 kgf-cm, 14 ft-lbf)**

**HINT:** Temporarily tighten the No.1 and No.2 bolts.




### 3. CHECK DIAPHRAGM SPRING TIP ALIGNMENT

Using a dial indicator with roller instrument, check the diaphragm spring tip alignment.


**Maximum non-alignment:**

**0.5 mm (0.020 in.)**



If alignment is not as specified, using SST, adjust the diaphragm spring tip alignment.



SST 09333-00013



### 4. APPLY MOLYBDENUM DISULPHIDE LITHIUM BASE GREASE (NLGI NO.2)

Apply molybdenum disulphide lithium base grease the following parts:

- Release fork and hub contact point
- Release fork and push rod contact point
- Release fork pivot point
- Release bearing retainer
- Release bearing

**5. APPLY SPLINE GREASE TO INPUT SHAFT SPLINE****6. INSTALL BOOT, FORK, HUB AND BEARING ON TRANSAXLE****7. INSTALL TRANSAXLE**

(See page S54 [MX-8](#) and E153 [MX-9](#))