


BALL JOINT COMPONENTS

SA08C-01




BALL JOINT ON-VEHICLE INSPECTION

1. INSPECT BALL JOINTS FOR EXCESSIVE LOOSENESS

- Jack up the front of the vehicle and place a wooden block with a height of 180–200 mm (7.09–7.87 in.) under one front tire.
- Lower the jack until there is about half a load on the front coil spring. Place stands under the vehicle for safety.
- Make sure the front wheels are in a straight forward position and block the wheel with chocks.
- Move the lower arm up and down check that the ball joint no excessive play.


Ball joint vertical play:

0 mm (0 in.)




BALL JOINT REMOVAL


1. JACK UP VEHICLE AND REMOVE FRONT WHEEL
2. DISCONNECT LOWER ARM FROM BALL JOINT
 - (a) Remove the cotter pin and nut.



- (b) Using SST, disconnect the lower arm from the ball joint.
SST 09610-20012



3. REMOVE BALL JOINT FROM AXLE CARRIER
Remove the two bolts and ball joint.



BALL JOINT INSPECTION


1. INSPECT BALL JOINT FOR ROTATION

- (a) Remove the ball joint.
- (b) Flip the ball joint stud back and forth 5 times as shown in the figure, before installing the nut.
- (c) Using a torque gauge, turn the nut continuously one turn each 2-4 seconds and take the torque reading on the fifth turn.

Torque (turning):

0.8 N-m (8-25 kgf-cm, 7-22 in.·lbf)

If not within specification, replace the ball joint.




BALL JOINT INSTALLATION

1. INSTALL BALL JOINT TO AXLE CARRIER

Install ball joint to the axle carrier with the two bolts.

Torque: 80 N-m (820 kgf-cm, 59 ft-lbf)



2. CONNECT BALL JOINT TO LOWER ARM

(a) Connect the ball joint to lower arm with the nut.

Torque: 78 N-m (800 kgf-cm, 58 ft-lbf)

(b) Install a new cotter pin.