



LOWER SUSPENSION ARM COMPONENTS

SA008-01



R02849




LOWER ARM REMOVAL

SA008-01

1. JACK UP VEHICLE AND REMOVE REAR WHEEL
2. DISCONNECT LOWER ARM FROM BALL JOINT


- (a) Remove the cotter pin and nut.
- (b) Using SST, disconnect the lower arm from the ball joint.

SST 09628-62011




3. REMOVE STRUT BAR NUT AND RETAINER

Remove the strut bar nut and retainer from the lower arm.



4. REMOVE LOWER ARM


- Remove the bolt holding the lower arm to the body and remove the lower arm.
- Remove the strut bar cushions, collar and retainer from the lower arm.




LOWER ARM INSTALLATION

1. INSTALL LOWER ARM

- Install the strut bar retainer, cushions, and collar to the strut bar.
- Connect the lower arm to the strut bar.
- Temporarily install a new strut bar nut.




- Install the lower arm to the body. Do not torque the bolt.




2. CONNECT LOWER ARM TO BALL JOINT

- Connect the lower arm to the ball joint.
- Install the nut.
Torque: 91 N-m (930 kgf-cm, 67 ft-lbf)
- Install a new cotter pin.



3. STABILIZE SUSPENSION


- Install the rear wheel and lower vehicle.
Torque: 103 N-m (1,050 kgf-cm, 76 ft-lbf)
- Bounce the vehicle up and down several times to allow the suspension to settle.



4. TORQUE LOWER ARM HOLDING NUT

- (a) Torque the strut bar nut with the vehicle load applied on the suspension.

Torque: 118 N-m (1,200 kgf.cm, 87 ft.lbf)



- (b) Torque the lower arm holding nut with the vehicle load applied on the suspension.

Torque: 103 N-m (1,050 kgf-cm. 76 ft-lbf)

5. CHECK REAR WHEEL ALIGNMENT

(See page [SA-3](#))