



CRUISE CONTROL SYSTEM PARTS LOCATION




WIRING DIAGRAM (USA)



The POWER SOURCE CIRCUIT has been simplified. For full details, see page BE-9.

(CANADA)




The POWER SOURCE CIRCUIT has been simplified. For full details, see page BE-9.

CONNECTOR DIAGRAMS


Cruise Control Switch

(USA)



e-6-1-C

(CANADA)




Connector "A"

Connector "B"

V-34-2

Stop Light Switch




BE5656

Clutch Switch (M/T)




G-2-2

Parking Brake Switch




BE1412

Park/Neutral Switch (A/T)




SH-9-2-A

Cruise Control ECU




Vd-26-2-B

Actuator



Ie-7-2

Starter Relay





ST0280

Throttle Position Sensor

(3-Pin Type)

(4-Pin Type)




AC2241


Vehicle Speed Pulse Generator

(M/T)

(A/T)



N04050



N04051

SYSTEM DESCRIPTION

- When the ignition switch is turned ON, current flows from the battery to terminal 14 of the cruise control (CC) ECU.
- Terminal 13 of the CC ECU is always grounded.

BASIC OPERATION

HINT: For all explanations below, the ignition switch is in the ON position.

1. CONTROL SWITCH OPERATION

- The CC switch controls MAIN switch, SET/COAST, RESUME/ACCEL and CANCEL functions.

(USA)

(a) MAIN switch

When the main switch is pushed ON, current flows from terminal 4 of the CC ECU – terminal 5 of the control switch – terminal 3 of the switch – ground.

As a result, the CC ECU is on standby and terminal 5 of the CC ECU is grounded. Therefore the CC indicator lights up.

(b) SET/COAST, RESUME/ACCEL and CANCEL switch

The control switch controls the SET, COAST, RESUME, ACCEL and CANCEL functions. When the control switch is turned to each position, current flows from terminal 18 of the CC ECU – terminal 4 of the control switch → (each resistance) → terminal 3 of the switch → ground.

In the way, the CC ECU detects each position the control switch is turned to, and starts operation.

HINT: The SET function is detected by the CC ECU when the control switch released from SET/COAST.

(CANADA)

(a) MAIN switch

When the main switch is pushed ON, current flows from terminal 4 of the CC ECU → terminal 15 of the control switch → terminal 19 of the switch → ground.

As a result, the CC ECU is on standby and terminal 5 of the CC ECU is grounded. Therefore the CC indicator lights up.

b) SET/COAST switch

When the control switch is turned to SET/COAST position, the current flows from terminal 19 of the CC ECU → terminal 5 of the CC switch → terminal 19 of the CC switch → ground.

c) RESUME/ACCEL switch

When the control switch is turned to RESIACC position, the current flows from terminal 18 of the CC ECU → terminal 17 of the CC switch → terminal 19 of the CC switch → ground.

d) CANCEL switch

When the control switch is turned to CANCEL position, the current flows from terminal 17 of the CC ECU → terminal 11 of the CC switch → terminal 19 of the CC switch → ground.

SPEED CONTROL OPERATION

When the vehicle speed is set by the control switch, the ECU sends signal from terminal 10 → terminal 2 of the stop light switch → terminal 4 of the switch → terminal 5 of the actuator → (safety magnetic clutch) – terminal 4 of the actuator → ground.

When the actual vehicle speed drops below the set speed, the CC ECU sends a signal (voltage) from terminal 12 → terminal 6 of actuator → (motor) → terminal 7 of actuator → terminal 11 of CC ECU.

This causes the motor to rotate the actuator arm in the throttle opening direction, increasing the vehicle speed. Then, when the arm reaches the prescribed angle, the CC ECU detects this at terminal 25 and stops the signal from 12.

When the actual vehicle speed rises above the set speed, the CC ECU sends a signal from terminal 11, turning the motor in the opposite direction so that the vehicle speed is reduced.

The CC ECU sends approx. 5 V from terminal 24 → terminal 1 of the actuator → (position sensor) → terminal 3 of the actuator → terminal 26 of the CC ECU. When the occurs, the position sensor sends the position of the actuator arm as a signal (voltage) from terminal 2 of the actuator to terminal 25 of the CC ECU.


3. MANUAL CANCEL OPERATION

The CC system has the following methods of cancellation:

- **Speed Control Switch (CANCEL)**
When the control switch is turned to CANCEL position.
- **Parking Brake Switch**
When the parking brake lever is pulled, the parking brake switch is turned ON and sends a cancellation signal (ground voltage) to terminal 3 of the CC ECU.
- **Park/Neutral Switch (A/T)**
When the shift lever is set to "N" or "P" range, the park/neutral switch is turned ON and sends a cancellation signal (ground voltage) to terminal 2 of the CC ECU.
- **Clutch Switch (M/T)**
When the clutch pedal is depressed, the clutch switch is turned ON and sends a cancellation signal (ground voltage) to terminal 2 of the CC ECU.
- **Stop Light Switch**
When the brake pedal is depressed, SW B of the stop light switch is turned OFF, the safety magnetic clutch (in actuator) is released, and SW A of the stop light switch is turned ON and sends a cancellation signal (battery voltage) to terminal 16 of the CC ECU.

When the CC ECU detects any of the above signals, it stops output of signals to the actuator, and cancels cruise control.

CC: Cruise Control



DIAGNOSIS SYSTEM

OUTPUT OF DIAGNOSIS CODE

READ DIAGNOSIS CODE

- (a) If while driving with the cruise control on, the system is canceled by a malfunction in either the actuator, speed sensor or speed control switch circuit, the cruise control indicator light "CRUISE" will blink 5 times.
- (b) While stopped, connect terminals 3 and 11 of the check connector.

HINT: If the ignition switch is turned off, the diagnostic code will be erased from the computer memory.


- (e) Read the diagnostic code on the indicator light "CRUISE".

	Indicator code	Diagnosis
	<p>BE1939</p>	Normal
11	<p>BE1940</p>	Excessive current flowed to motor or safety magnetic clutch drive circuit.
12	<p>BE2711</p>	Open circuit in safety magnetic clutch circuit.
13	<p>BE4344</p>	Position sensor circuit abnormal. Open circuit in motor.
21	<p>BE1941</p>	Vehicle speed signal not sent for 140 msec. or longer.
22	<p>BE1942</p>	Vehicle speed pulse generator (in Powertrain Control Module) circuit is abnormal.
23	<p>BE1943</p>	(A/T) Vehicle speed has decreased by 16 km/h (10 mph) or more from the set speed during cruising.
31	<p>BE1944</p>	(CANADA) RESUME/ACCEL switch is ON always when MAIN switch is pushed ON.
32	<p>BE1945</p>	(USA) Short circuit in control switch circuit.
33	<p>BE2712</p>	(CANADA) SET/COAST switch signal and RES/ACC switch signal turned on simultaneously.
34	<p>BE4342</p>	(USA) Control switch does not turn off before switching.
41	<p>BE4345</p>	ECU malfunction.

If the set speed can be maintained when the speed control switch is again set at SET/COAST, there is no malfunction.

HINT:

- Indication codes appear in order from No. 11.
- If there is no indication code, perform troubleshooting and inspection. (See page [BE-124](#)).



INPUT SIGNAL CHECK

Output Code

1. (a) For check No. 1 – No. 2
Turn the ignition switch on.
- (b) For check No. 3 – No. 4
Jack up the vehicle.
Start the engine.
2. Turn the control switch to SET/COAST position and hold it down (1).
3. Push the main switch on (2).
4. Check that the CRUISE MAIN indicator light blinks twice repeatedly.
5. Turn the SET/COAST switch off.
6. Operate each switch as listed in the table below.
7. Read the blinking pattern of the CRUISE MAIN indicator light.
8. After performing the check, turn the main switch off.

HINT: When two or more signals are input to the ECU, only the lowest-numbered code is displayed.

No.	Operation Method	CRUISE MAIN Indicator Light Blinking Pattern	Diagnosis
1	Turn SET/COAST switch ON.	Light ON BE4006 OFF	SET/COAST switch circuit is normal.
2	Turn RES/CC switch ON.	Light ON BE4006 OFF	RES/ACC switch circuit is normal.
3	Turn CANCEL switch ON.	Light ON BE4006 OFF	CANCEL switch circuit is normal.
	Turn stop fight switch ON. (Depress brake pedal)		Stop fight switch circuit is normal.
	Turn parking brake switch ON. (Release parking brake)		Parking brake switch circuit is normal.
	Turn park/neutral switch ON. (Shift to N or P range)		Park/neutral switch circuit is normal.
4	Drive at 40 km/h (25 mph) or higher.	Light ON BE4006 OFF	Vehicle speed pulse generator is normal.
	Drive at 40 km/h (25 mph) or below.	Light ON BE4006 OFF	


TROUBLESHOOTING

You will find the source of the trouble more easily be properly using the table shown below. In this table, the numbers indicate the order of priority of the causes of trouble. Check each part in the order shown.

Chart No.			H	*1	*2	L	N, O	M	*3	P	Q			
Inspection Item														
Diagnosis Code			CC/ECU	Actuator	Main Switch (in Control Switch)	Control Switch	Stop Light Switch	Clutch Switch or Park/Neutral Switch	Parking Brake Switch	Vehicle Speed Pulse Generator or Speedometer Cable	ECT Solenoid No. 2 Circuit	Throttle Position Sensor (IDL)	Speed Control Cable Function	Wire Harness
Problem		Type B	Type A											
<ul style="list-style-type: none"> "CRUISE" Indicator light blinks 5 times. Cruise control system does not set. Cruise control system does not operate 	11		3	2										1
	12		4	2			3							1
	13		3	2										1
	21		3							2				1
	22		2							1				
	23		4	3						2			1	
	31		3			2								1
	32		2			1								
	33		3			2								1
	34		2			1								
	41		1											
	Normal	4	OK	9	8	2	3	4	5	6			7	1
			NG	2							7			
Set speed deviates on high or low side			4	3						1			2	
Large speed drop when the speed control switch turned to SET.			4	3								2	1	
Vehicle speed fluctuates when speed control switch turned to SET.			4	3						1			2	
Acceleration response is sluggish when speed control switch turned to "ACCEL" or "RESUME"			4	3						2			1	
During autodrive operation, shift operation occurs frequently without control			2								1			
Set speed does not cancel when brake pedal depressed.	3		OK	1										
			NG	2			1							
Set speed does not cancel when parking brake lever pulled.	3		OK	1										
			NG	2				1						
Set speed does not cancel when clutch pedal depressed.	3		OK	1					1					
			NG	2										
Set speed does not cancel when speed control switch turned to CANCEL.	3		OK	1			1							
			NG	2										
Vehicle speed does not decrease when speed control switch turned to COAST.	1		OK	4	1					3			2	
			NG	2			1							
Vehicle speed does not accelerate when speed control switch turned to ACCEL.	2		OK	4	1					3			2	
			NG	2			1							
Vehicle speed does not return to memorized speed when control switch turned on RESUME	2		OK	4	1					3			2	
			NG	2			1							
Speed can be set below about 40 km/h (25 mph.)	4		OK	1										
			NG	2						1				
Cruise control will not disengage even at about 40 km/h (25 mph.)	4		OK	1										
			NG	3						1			2	
*1 USA : C CANADA : D *2 USA : C CANADA : E, F, G *3 M/T : I A/T : J, K														

A POWER SOURCE CIRCUIT


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

B CRUISE CONTROL INDICATOR CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control

C CONTROL SWITCH CIRCUIT (USA)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.


CONTROL SWITCH



CC: Cruise Control

D MAIN SWITCH CIRCUIT (CANADA)


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected,
CONTROL SWITCH




E SET/COAST SWITCH CIRCUIT (CANADA)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CONTROL SWITCH



CC ECU




CC: Cruise Control

F RES/ACC SWITCH CIRCUIT (CANADA)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CONTROL SWITCH



G CANCEL SWITCH CIRCUIT (CANADA)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

CONTROL SWITCH

¹ Disconnect connector from control switch and inspect connector on wire harness side as follows.

INSPECT GROUND CONNECTION
Is there continuity between terminal 19 and ground?

No

- Open circuit in wire harness between terminal 19 of control switch and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH
(See page BE-137)
Is control switch operation normal?

No

Replace control switch. Then recheck system.

Yes

CC ECU

Connect connector to control switch.
Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

INSPECT CANCEL CIRCUIT
Is there continuity between terminal 17 and ground with control switch turned to CANCEL position?

No

Open circuit in wire harness between terminal 17 of CC ECU and terminal 11 of control switch.

Yes

Is there continuity between terminal 17 and ground with control switch released?

Yes

Short circuit in wire harness between terminal 17 of CC ECU and terminal 11 of control switch.


No


Replace CC ECU.
Then recheck system.

CC: Cruise Control

H	ACTUATOR CIRCUIT
----------	-------------------------

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

ACTUATOR




CC: Cruise Control

VEHICLE SPEED PULSE GENERATOR CIRCUIT (with M/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

VEHICLE SPEED PULSE GENERATOR



CC: Cruise Control

J VEHICLE SPEED PULSE GENERATOR CIRCUIT (with A/T: COMBINATION METER)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

COMBINATION METER

Disconnect connector "A" from combination meter and inspect connector on wire harness side as follows.

INSPECT GROUND CONNECTION
Is there continuity between terminal A-1 and ground?

No

- Open circuit in wire harness between terminal A-1 of combination meter and ground.
- Ground faulty.

Yes

INSPECT CONTROL SWITCH (See page BE-137)
Is speed sensor operation normal?

No

Replace speedometer. Then recheck system.

Yes

CC ECU

Connect connector "A" to combination meter. Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

INSPECT VEHICLE SPEED PULSE GENERATOR CIRCUIT
Is there continuity repeatedly between terminal 20 and ground?

No

- Open or short circuit in wire harness between terminals 20 of CC ECU and B-10 of combination meter.
- Open or short circuit in circuit plate of combination meter between terminal B-10 and vehicle speed pulse generator.
- Open circuit in circuit plate of combination meter between terminal A-1 and vehicle speed pulse generator.


Yes

Replace CC ECU. Then recheck system.

CC: Cruise Control

K**VEHICLE SPEED PULSE GENERATOR CIRCUIT (with AM ECT)**


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected,

VEHICLE SPEED PULSE GENERATOR

CC: Cruise Control

L STOP LIGHT SWITCH CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CONTINUED FROM PREVIOUS PAGE

STOP LIGHT SWITCH

Disconnect connector from stop light switch and inspect connector— on wire harness side as follows.

INSPECT POWER SOURCE
Is there battery voltage between terminal 1 and ground?

No

Open circuit in wire harness between terminal 1 of stop light switch and STOP fuse.

Yes

INSPECT STOP LIGHT CIRCUIT
Connect terminals 1 and 3.
Do stop light lights up?

No

- Open circuit in wire harness between terminal 3 of stop light switch and ground.
- Ground faulty.

Yes

INSPECT STOP LIGHT SWITCH
(See page BE-137)
Is stop light switch operation normal?

No

Replace stop light switch. Then recheck system.

Yes

CC ECU

Connect connector to stop light switch. Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

If stop light system operation is normal, start inspection from this step.

INSPECT STOP LIGHT SWITCH CIRCUIT
Is there battery voltage between terminal 1 and ground?

No

Open circuit in wire harness between terminal 1 of CC ECU and STOP fuse.

Yes

Is there battery voltage between terminal 16 and ground when brake pedal depressed?

No

Open circuit in wire harness between terminals 16 of CC ECU and 3 of stop light switch.


Yes

Replace CC ECU. Then recheck system.

CC: Cruise Control

M**PARKING BRAKE SWITCH CIRCUIT**

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control

N CLUTCH SWITCH CIRCUIT (with M/T)

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.


CLUTCH SWITCH



CC: Cruise Control

O **PARK/NEUTRAL SWITCH CIRCUIT (with A/T)**


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.



CC: Cruise Control

P **ECT SOLENOID No. 2 CIRCUIT (with A/T)**


HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.




CC: Cruise Control

Q IDL SIGNAL CIRCUIT

HINT: While carrying out the following inspection, make certain that the connectors and terminals are properly connected.

THROTTLE POSITION SENSOR


Wire Harness Side



Vd-26-1-B

CRUISE CONTROL ECU

CRUISE CONTROL ECU INSPECTION

ECU CIRCUIT

Disconnect connector and inspect connector on wire harness side as shown in the chart.


(USA)

Check for	Measured item	Tester connection	Condition		Specified Value	
Continuity	Clutch Switch (M/T)	2 – ground	Clutch pedal position	released	No continuity	
				depressed	Continuity	
	Park/Neutral switch (Alt)	2 – ground	Shift lever position	Nor P	Continuity	
				L,2,D or R	No continuity	
	Parking brake switch	3 – ground	Parking brake lever position	released	No continuity	
				pulled	Continuity	
	Control switch	4 – ground	Main switch position	pushed	Continuity	
				released	No continuity	
	Actuator (motor)	11–12	Actuator arm position	max. OPEN		(12 → 11) Continuity
				max. CLOSE		(11 → 12) No continuity
any position except above position				(11 → 12) Continuity		
any position except above position				(12 → 11) No continuity		
Ground connection	13 – ground	Constant			Continuity	
Resistance	Actuator (Safety magnetic clutch)	10 – ground	Brake pedal position	released	Approx. 38.5 92	
				depressed	No continuity	
	Control switch	18 – ground	Control switch position	OFF	No continuity	
				RES/ACC	Approx. 68Ω	
				SET/COAST	Approx. 198Ω	
				CANCEL	Approx. 418 92	
	ECT No. 2 solenoid valve (A/T)	22 – ground	Constant			Approx. 13Ω
Actuator (position sensor)	24–26	Constant			Approx. 2 kΩ	
	25–26	Actuator arm turned	Resistance change even			
Voltage	STOP fuse	1 – ground	Constant			Battery voltage
	Power source	14 – ground	Ignition switch position	LOCK or ACC	No voltage	
				ON	Battery voltage	
	Stop light	16 – ground	Brake pedal position	released	No voltage	
				depressed	Battery voltage	
Vehicle speed pulse generator	20 – ground	With ignition switch ON, speedometer shaft or speed sensor shaft turned.			Voltage changes repeatedly	

(CANADA)

Check for	Measured item	Tester connection	Condition		Specified Value	
Continuity	Clutch switch	2 – ground	Clutch pedal position	released	No continuity	
				depressed	Continuity	
	Parking brake switch	3 – ground	Parking brake lever position	released	No continuity	
				pulled	Continuity	
	MAIN switch**	4 – ground	Main switch position	pushed	Continuity	
				released	No continuity	
	Actuator (motor)	11–12	Actuator arm position	max. OPEN		(12 → 11) Continuity
						(11 → 12) No continuity
				max. CLOSE		(11 → 12) Continuity
						(12 → 11) No continuity
				any position except above position		(11 ↔ 12) Continuity
	Ground connection	13 – ground	Constant			Continuity
	CANCEL switch*1	17 – ground		Cruise control switch position	turned to "CANCEL"	Continuity
released					No continuity	
RES/ACC switch*1	18 – ground		Cruise control switch position	turned to "RES/ACC"	Continuity	
				released	No continuity	
SET/COAST switch *1	19 – ground		Cruise control switch position	turned to "SET/COAST"	Continuity	
				released	No continuity	
Resistance	Actuator (Safety magnetic clutch)	10 – ground	Brake pedal position	released	Approx. 38.5Ω	
				depressed	No continuity	
	Actuator (position sensor)	24–26	Constant			Approx. 2 Ω
25–26		Actuator arm turned	Resistance change even			
Voltage	STOP fuse	1 – ground	Constant			Battery voltage
	Power– source	14 – ground	Ignition switch position	LOCK or ACC	No voltage	
				ON	Battery voltage	
	Stop light	16 – ground	Brake pedal position	released	No voltage	
				depressed	Battery voltage	
Vehicle speed pulse generator	20 – ground	With ignition switch ON, speedometer shaft or vehicle speed pulse generator shaft turned.			Voltage changes repeatedly	
** There is on cruise control switch.						

USA



BE4009
e-6-1-C

CRUISE CONTROL SWITCH CRUISE CONTROL SWITCH INSPECTION

CONTINUITY: USA Models

(a) Check continuity between terminals 3 and 5.



Main switch position	Condition
OFF	No continuity
ON	Continuity

(b) Measure resistance between terminals 3 and 4.

Control switch position	Resistance (Ω)
OFF	∞ (No continuity)
RES/ACC	Approx. 68
SET/COAST	Approx. 198
CANCEL	Approx. 418

If resistance value is not as specified, replace the control switch.

CANADA



Connector "A" Connector "B"

BE4909
V-34-2

CONTINUITY: CANADA Models

Terminal	B-5	B-11	B-15	B-17	6-19
Switch Position					
OFF					
RES/ACC				○—○	
MAIN			○—○		
SET/COAST	○—○				
CANCEL		○—○			



If continuity is not as specified, replace the switch.

PARKING BRAKE SWITCH PARKING BRAKE SWITCH INSPECTION

See Brake Warning System on page [BE-79](#).

STOP LIGHT SWITCH STOP LIGHT SWITCH INSPECTION

CONTINUITY



BE1444 BE5656


Terminal	1	2
Switch position		
Switch pin free (Brake pedal depressed)	○—○	○—○
Switch pin pushed in (Brake pedal released)		

If continuity is not as specified, replace the stop light switch.

CLUTCH SWITCH

CLUTCH SWITCH INSPECTION

CONTINUITY: M/T Models

 BE2737 G-2-2	Terminal	1	2
	Condition		
	Switch pin free (Clutch pedal depressed)	○—○	○—○
Switch pin pushed in (Clutch pedal released)			

If continuity is not as specified, replace the switch.

PARK/NEUTRAL SWITCH


PARK/NEUTRAL SWITCH INSPECTION

See page [AX-35](#).

STARTER RELAY

STARTER RELAY INSPECTION


CONTINUITY

 ST0280 BE1840	Terminal	1	2	3	4
	Condition				
	Constant	○—○	○—○		
Apply battery voltage to terminals 1 and 3.		○—○		○—○	


If continuity is not as specified, replace the relay.

Vehicle Speed Pulse Generator Shaft

(M/T)



(A/T)



N04050
N04051

VEHICLE SPEED PULSE GENERATOR



VEHICLE SPEED PULSE GENERATOR INSPECTION

INSPECT VEHICLE SPEED PULSE GENERATOR

- Connect the positive (+) lead from battery to terminal 1 and negative (-) lead to terminal 2.
- Connect the positive (+) lead from tester to terminal 3 and negative (-) lead to terminal 2.
- Revolve shaft.
- Check that there is voltage change from approx. 0V to 11V or more between terminal 3 and 2.

HINT: The voltage change should be 4 times per each revolution of the vehicle speed pulse generator shaft.

If operation is not as specified, replace the generator.




ACTUATOR

ACTUATOR INSPECTION

SAFETY MAGNETIC CLUTCH


(a) Check that the arm moves smoothly by hand.



(b) Connect the positive (+) lead from the battery to terminal 5 and the negative H lead to terminal 4. (Safety Magnetic Clutch turned ON)

(c) Check that the arm does not move by hand.


If operation is not as specified, replace the motor.



MOTOR


(a) With the safety magnetic clutch ON, connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 7, check that the arm moves to the open side.

(b) When the arm reached to the open position, check that the motor operation stops.



(c) With the safety magnetic clutch ON, connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 6, check that the arm moves to the close side.


(d) When the arm reaches to the closed position, check that the motor operation stops.



POSITION SENSOR


- (a) Measure the resistance between terminals 1 and 3.

Resistance: Approx. 2 Ω



- (b) When the arm is moving from the closed to open position, check that resistance between terminals 2 and 3 increases from approx. 0.5 to 1.7 k Ω .

If operation is not as specified, replace the motor.



CRUISE CONTROL CABLE

- (a) Check that the cruise control cable freeplay is less than 10 mm (0.39 in.).
- (b) If necessary adjust the cruise control cable freeplay.

THROTTLE POSITION SENSOR

THROTTLE POSITION SENSOR INSPECTION

See page FI-134 and FI-141.