





PREPARATION

SST (SPECIAL SERVICE TOOLS)

SA0AV-01

	<p>09308-00010 Oil Seal Puller</p>	
	<p>09520-00031 Rear Axle Shaft Puller</p>	
	<p>09608-30012 Front Hub & Drive Pinion Bearing Tool Set</p>	
	<p>(09608-04020) Handle</p>	
	<p>(09608-04060) Front Hub Outer Bearing Cup Replacer</p>	
	<p>(09608-04070) Front Hub Inner Bearing Cup Replacer</p>	
	<p>09628-10011 Ball Joint Puller</p>	
	<p>09649-17010 Steering Knuckle Tool</p>	
	<p>09950-20017 Universal Puller</p>	

SA0AW-01

RECOMMENDED TOOLS

	<p>09905-00013 Snap Ring Pliers</p>	
---	-------------------------------------	--

SA0AX-01

EQUIPMENT

<p>Dial indicator</p>	
<p>Torque wrench</p>	